



401 South Grand Ave., Santa Ana, CA 92705
Tel: 714.550.6070 Fax: 714.550.9661 www.twobros.com



2008 Can-Am SPYDER 990

V.A.L.E.™ Slip-on Exhaust System with M-2 Canister
Part # 005-2290406V / 005-2290407V / 005-2290408V



Parts List



| Qty. | Description | Part Number |
|------|----------------------------------|-------------|
| 1 | M-2 Muffler Canister | Varies |
| 1 | Slip-On Tube | 005-22901S |
| 1 | HARDWARE KIT | 005-229-3 |
| 2 | X-Ring (half) | 005-7-2-3 |
| 1 | Aluminum Spacer | 005-229-S2 |
| 1 | Muffler Clamp | Varies |
| 1 | Rubber Clamp Liner | 005-LC |
| 1 | 10x75mm Socket Head Cap Screw | 005-SH1075 |
| 4 | 6x14mm Socket Head Cap Screw | 005-SH614 |
| 4 | 6mm Lock Washer | 005-WL6 |
| 1 | High Temp Silicon | 013-P22072 |
| 1 | 5mm Long Handle Ball End Hex Key | 005-9-18610 |
| 1 | T20 Torx Short Hex Key | 005-9-15820 |
| 1 | Spring | 005-S80 |
| 1 | TBR Sticker Kit | 015-10212 |

IMPORTANT - PLEASE READ CAREFULLY

We recommend that this performance part be installed by a qualified motorcycle technician. If you have any doubts as to your ability to install this performance part, please consult with your local motorcycle dealer. Read all instructions first before starting installation. Make sure the motorcycle and exhaust system are completely cool before starting the installation. Also, make sure the bike is secure on a centerstand or ideally a service lift during installation. Be sure to save all stock components for possible use later.

Installation Instructions

1. Make sure the bike is completely cool before starting the installation. Make sure the bikes parking brake is set.
2. Remove OEM Muffler assembly.
3. Remove OEM Gasket.



4. Install slip-on tube to TBR muffler using the 6x14mm socket head cap screws and lock washers provided, leave loose for now.



V.A.L.E.™ Assembly Detail

5. Remove OEM spacer from mounting point.



6. Install new TBR spacer in same location as previously removed sleeve.



7. Place a bead of high temp silicone on inside edge of slip-on tube where it will meet OEM header assembly.

8. Install TBR muffler assembly to machine.



9. Slide rubber lined muffler clamp over muffler and attach using the supplied 10x75mm socket head cap screws and OEM nut and washer.



10. Make sure everything is aligned and tighten all hardware.



(Continued on page 2)



401 South Grand Ave., Santa Ana, CA 92705
Tel: 714.550.6070 Fax: 714.550.9661 www.twobros.com



**2008 Can-Am
SPYDER 990**

V.A.L.E.™ Slip-on Exhaust System with M-2 Canister
Part # 005-2290406V / 005-2290407V / 005-2290408V

(Continued from page 1)

11. Attach spring to spring clip.



12. Before you run the bike, clean off all fingerprints and dirt, as any oily residue will etch the metal and become somewhat permanent when the system gets hot. Run the bike and enjoy. It is normal for some white smoke to appear the first time you start the bike. This is packing/manufacturing oil from inside the pipe burning off. Check for gaps or leaks. If you find a leak, a little high temperature silicon sealant should fix it. After 50 to 100 miles, recheck all fasteners for tightness.

Repack Carbon Fiber and Titanium mufflers every 10 hours, repack Aluminum mufflers every 15 hours. There is no warranty provided for improper care and maintenance of exhaust systems.

005-2290406V



005-2290407V



005-2290408V



Parts List

| Qty. | Description | Part Number |
|------|----------------------------------|-------------|
| 1 | M-2 Muffler Canister | Varies |
| 1 | Slip-On Tube | 005-22901S |
| 1 | HARDWARE KIT | 005-229-3 |
| 2 | X-Ring (half) | 005-7-2-3 |
| 1 | Aluminum Spacer | 005-229-S2 |
| 1 | Muffler Clamp | Varies |
| 1 | Rubber Clamp Liner | 005-LC |
| 1 | 10x75mm Socket Head Cap Screw | 005-SH1075 |
| 4 | 6x14mm Socket Head Cap Screw | 005-SH614 |
| 4 | 6mm Lock Washer | 005-WL6 |
| 1 | High Temp Silicon | 013-P22072 |
| 1 | 5mm Long Handle Ball End Hex Key | 005-9-18610 |
| 1 | T20 Torx Short Hex Key | 005-9-15820 |
| 1 | Spring | 005-S80 |
| 1 | TBR Sticker Kit | 015-10212 |

Care & Cleaning

Care & Cleaning

Keep system free of dirt and moisture. Store in a cool, dry place. Make sure vehicle is completely cool before maintenance.

Stainless Header System: Polished stainless steel pipes will turn a light golden hue after a few heat cycles, this is a normal characteristic of high quality stainless steel. Clean using a mild water based spray cleaner. Always apply cleaner or polish with a soft, clean cloth.

Titanium Header System: Polished titanium pipes will experience color shift ranging from deep blue/purple through amber after a few heat cycles. This is a normal characteristic of high quality titanium. Clean using a mild water based spray cleaner. Always apply cleaner or polish with a soft, clean cloth.

Polished Aluminum Canisters: Use an aluminum or mag wheel polish to restore the bright finish to factory spec.

Brushed Aluminum Canisters: Clean using a mild water based spray cleaner. Always apply cleaner or polish with a soft, clean cloth.

Carbon Fiber Canisters: Clean using a mild water based spray cleaner. Always apply cleaner or polish with a soft, clean cloth. Always make sure the fiberglass packing inside is in good condition and not burned out, as exhaust heat inside an empty canister will deteriorate the carbon fiber sleeve.

TBR sells repack kits (Road - #005-10038, Offroad - #005-10038MX) that include everything you need to easily do it yourself.

Titanium Mufflers: For cleaning use a mild water based spray cleaner. Always apply cleaner or polish with a soft, clean cloth. Always make sure the fiberglass packing inside is in good condition and not burned out, as exhaust heat inside an empty canister will deteriorate the carbon fiber sleeve.

TBR sells repack kits (Road - #005-10038, Offroad - #005-10038MX) that include everything you need to easily do it yourself.

Repack all road canisters every 3,000 miles. Part #005-10038

Repack all offroad canisters after every 10 hours of use. Part #005-10038MX

NEVER dyno test your bike with carbon fiber or titanium canisters installed - the intense heat and lack of cooling air can quickly burn through the canister material. Two Brothers Racing does not provide a warranty for burned canisters.

Warranty

Two Brothers Racing products are intended for closed course competition purposes only, and therefore are sold "as is" without warranty. Two Brothers Racing specifically disclaims any warranties of merchantability or fitness for a particular purpose and disclaims all responsibility for consequential and incidental damages or any other losses arising from the use of these products or parts.